


Operating Manual



GEDA® **MULTILIFT P22**

Construction hoist

For transporting material and persons

Original Operating Manual





EU Declaration of Conformity

The manufacturer:

GEDA GmbH

Mertinger Strasse 60

86663 Asbach-Bäumenheim

hereby declares that the machine

Designation: Construction hoist for transporting material and persons
(for temporary use in non-public areas by authorised persons)

Type: GEDA MULTILIFT P22 Serial number: P22...
starting from: 00450

Type: GEDA MULTILIFT P22 Serial number: 41M00400 - 41M00408

Year of construction: Refer to name plate on the machine

is in compliance with all pertinent provisions of the following directives at the time of being put on the market.

Directives:

2006/42/EU Machinery Directive
2014/35/EU Low Voltage Directive
2014/30/EU EMC Directive
2000/14/EU Noise Emissions Directive

Conformity evaluation procedures applied:

Appendix IX
Appendix IV
Appendix II
Appendix V

Applied (harmonised) standards:

EN ISO 12100:2010, EN 60204-1/32:2008, EN 12159:2012, following EN 12158-1:2000+A1:20210

EC Type test certification procedure:

Type test certification

EC-MRL 381

European notified test site

0036

TÜV SÜD Industrie Service GmbH
Westendstrasse 199
80686 Munich

This EU conformity declaration becomes null and void if any changes are made to the aforementioned machine that have not been authorised by the manufacturer.

The authorised representative for technical documentation is the signatory. For address refer to manufacturer.

Asbach-Bäumenheim
Date 05 2021

Johann Sailer
CEO GEDA GmbH

Table of contents

1	General information	9
1.1	Information on the operating manual	9
1.2	Abbreviations	12
1.3	Identification data	13
1.4	Manufacturer's name and address	13
1.5	Information about the author and industrial property rights	14
1.6	Patents	14
1.7	Instructions for the operating company	14
1.8	Intended use	16
1.8.1	Assembly, service/maintenance specialist	17
1.8.2	Operating personnel	17
1.8.3	Improper use	17
2	General safety information	18
2.1	Residual risks	18
2.2	Safety instructions for operating personnel	19
2.3	Safety instructions for transport	20
2.4	Safety instructions for operation	21
2.5	Safety instructions for maintenance and troubleshooting	22
2.6	Safety when working on the electric system	24
3	Technical data	25
3.1	Operating and environmental conditions	25
3.2	Emissions	26
3.3	Tightening torques	27
3.4	Electrical connected loads	28
3.5	Speeds	29
3.6	Heights	29
3.7	Vibrations in the car	30
3.8	Mast	30
3.9	Load capacity, dimensions and weights	33
4	Operation	36
4.1	Safety during operation	36
4.2	Commissioning	37
4.2.1	Fingerprint scanner (optional)	38
4.2.2	Safety check before starting work	39
4.3	Operation/function	40
4.3.1	Functional description	42
4.3.2	Base enclosure	43
4.3.3	Car access points	46
4.3.3.1	Vertical sliding door	46
4.3.3.2	Vertical sliding door with ramp	47
4.3.3.3	Car door emergency release	49
4.3.4	Securing loading and unloading points	50
4.3.4.1	"Standard/Standard Basic" landing level safety gate	50
4.3.4.2	"Comfort" landing level safety gate	53
4.3.4.3	Landing level double doors	55
4.3.5	Ground control	57

4.3.6	Landing level modules	58
4.3.6.1	Landing level module with stop	58
4.3.6.2	Landing level module with call control	59
4.3.7	Car controls	60
4.3.7.1	G-SAC car control with rotary/ push button	60
4.3.7.2	Car control G-SAC keypad	62
4.3.8	Controls for special operation	64
4.3.8.1	Drop test control	65
4.3.8.2	Assembly control	65
4.3.9	Emergency shutdown	66
4.4	Interrupting work – end of work	67
4.5	Equipment	68
4.5.1	Emergency call system	68
4.5.1.1	Alarm signal	69
4.5.2	Lighting	70
4.5.3	Roof hatch and ladder	71
4.5.4	Document and tool box	75
4.5.5	Operating hours counter	76
4.6	Accessories	77
4.6.1	Assembly crane	77
4.6.2	Assembly plank	78
4.6.3	Cold package	78
4.6.4	Wind sensor (option)	79
4.6.5	Lifting beam	80
5	Malfunctions – diagnosis – repair	81
5.1	Status display in the touch display (HMI)	81
5.1.1	Malfunctions without status message	83
5.2	Rectify fault	84
5.2.1	Motor is not delivering full power	84
5.2.2	Main switch/circuit breaker has tripped	84
5.2.3	Car has moved too high	85
5.2.4	Car has moved too low	86
5.2.5	Car does not stop at the selected landing level	87
5.2.6	Monitoring the locking of the assembly crane	88
5.2.7	Overload indication	88
5.2.8	Safety gear has triggered	89
5.3	Rescue after malfunction	90
5.3.1	Conduct in the event of a rescue/malfunction	90
5.3.2	Initial rescue measures	91
5.3.2.1	Recovery using the recall function	91
5.3.2.2	Rescue in the event of a status display	92
5.3.2.3	Self-rescue using EMERGENCY lowering device	93
5.3.2.4	Exiting the car	96
5.3.2.5	Recovery in accordance with emergency plan	96
5.4	Repair	97
6	Disposal	98
6.1	Information about the service life for EAC	98

Table of figures

Fig. 1: Vario Mast	30
Fig. 2: Anchoring diagram	31
Fig. 3: Dimensions of car	35
Fig. 4: Startup	37
Fig. 5: Touch display fingerprint scanner	38
Fig. 6: Touch display fingerprint scanner	38
Fig. 7: Multilift P22 overview 1	40
Fig. 8: Multilift P22 overview 2	41
Fig. 9: Base enclosure	43
Fig. 10: Double doors on the base enclosure	44
Fig. 11: Emergency release for the double doors	45
Fig. 12: Vertical sliding door	46
Fig. 13: Vertical sliding door from outside	47
Fig. 14: Vertical sliding door from inside	48
Fig. 15: Car door emergency release	49
Fig. 16: Standard landing level safety gate no. 01217/01268	50
Fig. 17: "Standard" landing level safety gate closed (tarpaulin)	51
Fig. 18: "Standard" landing level safety gate closed (filler plate)	51
Fig. 19: Opening/closing the "Standard" landing level safety gate	52
Fig. 20: "Comfort" landing level safety gate no. 01212	53
Fig. 21: "Comfort" landing level safety gate closed (tarpaulin)	53
Fig. 22: "Comfort" landing level safety gate closed (filler plate)	54
Fig. 23: Opening/closing the "Comfort" landing level safety gate	54
Fig. 24: Landing level double doors	55
Fig. 25: Emergency release on the landing level double doors	56
Fig. 26: Ground control	57
Fig. 27: Landing level module for stop at landing level	58
Fig. 28: Landing level module for call control	59
Fig. 29: Car control with rotary switch	60
Fig. 30: Car control with keypad	62
Fig. 31: Example for removing the cover plate	64
Fig. 32: Inserting control for special operation	64
Fig. 33 Drop test control	65
Fig. 34 Assembly control	65
Fig. 35: EMERGENCY STOP button	66
Fig. 36 Main switch	67
Fig. 37 Securing the main switch	67
Fig. 38: Ground station emergency call	68
Fig. 39: Car emergency call	68
Fig. 40: Alarm button in the car	69
Fig. 41: Car lighting	70
Fig. 42: Car control lighting	70
Fig. 43: Overview of roof hatch and ladder	71
Fig. 44: Ladder in the car	72
Fig. 45: Pull the ladder out of the mount	72
Fig. 46: Take the ladder out of the mount	72
Fig. 47: Attach the ladder to the roof hatch	73

Fig. 48: Unlock the roof hatch	73
Fig. 49: Open the roof hatch	74
Fig. 50: Document box	75
Fig. 51: Operating hours counter	76
Fig. 52: Assembly crane	77
Fig. 53: Control for assembly crane	77
Fig. 54: Assembly plank	78
Fig. 55: Cold package	78
Fig. 56: Wind sensor	79
Fig. 57: Lifting beam	80
Fig. 58: Touch display (HMI)	81
Fig. 59: Touch display – maintenance	82
Fig. 60: Touch display – malfunction	82
Fig. 61 Circuit breaker tripped	84
Fig. 62 Resetting the circuit breaker	84
Fig. 63: Drop test control for clearance run	85
Fig. 64: Drop test control for clearance run	86
Fig. 65 Platform control	87
Fig. 66: Locking bolt for assembly crane	88
Fig. 67: Recall function, car control	91
Fig. 68: Recall function, ground control	91
Fig. 69: Touch display, car	92
Fig. 70: Overview of emergency descent	93
Fig. 71: Emergency descent 1	94
Fig. 72: Emergency descent 2	94
Fig. 73: Emergency release for the car	95

1 General information

1.1 Information on the operating manual

This operating manual is an essential aid to operating the machine **successfully and hazard-free** (refer to chapter 2.1 Residual risks).

This operating manual contains important instructions on how to operate the machine **safely, correctly and efficiently**. Compliance with these instructions helps to avoid hazards and increases the reliability and service life of the machine.

The operating manual must be **available at the machine at all times** and must be read and applied by every person commissioned to work on/with the machine, e.g.:

- operation, fault elimination during work, disposal of operating materials and auxiliary supplies,
- assembly, maintenance (servicing, general maintenance, repair) and/or transport.



Assembly is described in the Assembly Manual for the machine.

The Assembly Manual also contains

- information on transport and storage
- information on the foundation and bearing load
- assembly plan
- anchoring geometry and anchoring forces



The inspection and maintenance work is described in the Maintenance Manual for the machine!

The Maintenance Manual also contains

- the maintenance schedule (wear checks)
- details for static tests, dynamic tests and the drop test (test weights, evaluation criteria)

You will come across a series of illustrations and symbols while reading this manual. These are intended to help you navigate and understand this manual. The different meanings are explained below.

Text format	Meaning
Bold type	Emphasises particularly important words/sections
• List	Identifies lists level 1
– List	Identifies lists level 2
(brackets)	Item numbers
➤ Task instruction	Task instructions for personnel. Always given in chronological order

Images

The illustrations used refer to a specific machine type. They may only constitute a schematic representation of other machine types. The fundamental function and operation are not affected by this.

The structural elements in this operating manual appear as follows and have the following meaning:

1	...	5	Chronological sequence of work steps in illustrations
----------	-----	----------	---

⚠ DANGER

Type and source of the hazard: Danger to life

Consequence: Death/serious injury

Probability: imminent

➤ Measure for preventing the hazard

⚠ WARNING

Type and source: Risk of injury

Consequence: Serious injury

Probability: possible

➤ Measure for avoiding

⚠ CAUTION

Type and source: Risk of injury

Consequence: Minor injury

Probability: possible

➤ Measure for avoiding

ATTENTION

Type and source: Damage to the machine

Consequence: Property damage

Probability: possible

➤ Measure for preventing the damage

Safe working

Type and source: Failure to comply with health and safety regulations

Consequence: Risk for life and limb

Probability: possible

➤ Observe these instructions and proceed with caution.



Indicates information on using the machine economically or instructions for correct working procedures.

1.2 Abbreviations

The following abbreviations may be used in the manual.

Abbreviation:		Abbreviation:	
Max.	maximum	Fig.	figure
min.	minimum	Nm	Newton metre
Min.	minutes	km/h	kilometres per hour
etc.	et cetera	mph	miles per hour
		incl.	including
e.g.	for example		
ml	Millilitre	i.e.	that is
mm	Millimetre		
°C	degrees Celsius	RH	relative humidity
°F	degrees Fahrenheit	approx.	approximately
ft.	feet	Ø	diameter
ft/m	feet per minute	®	registered trademark
m/min	metres per minute	©	copyright
		TM	trademark
		%	per cent
lbs.	pounds	‰	per mil
lbf.-ft	pounds per feet	L _{PA}	sound pressure level
kg	kilogramme	L _{WA}	noise capacity level
L	litre	>	greater than
gal.	gallons	<	less than
kip.	kilopound	±	plus/minus

1.3 Identification data

Machine type:	GEDA MULTILIFT P22
Serial number:	P22...
Year of construction:	Refer to name plate
Documentation version:	2021-05

1.4 Manufacturer's name and address

GEDA GmbH
Mertinger Strasse 60
86663 Asbach-Bäumenheim
Tel.: +49 (0)9 06 / 98 09-0
Fax: +49 (0)9 06 / 98 09-50
E-Mail: info@geda.de
Web: www.geda.de

Representatives of the manufacturer

Bergkamen subsidiary	Gera subsidiary
GEDA GmbH Northwest Subsidiary Marie-Curie-Strasse 11 59192 Bergkamen-Rünthe Tel. +49(0)2389 9874-32 Fax. +49(0)2389 9874-33	GEDA GmbH Eastern Subsidiary Ernst-M.-Jahr Strasse 5 07552 Gera Tel. +49(0)365 55280-0 Fax. +49(0)365 55280-29
U.S. subsidiary	Russia subsidiary
GEDA USA, LLC 1151 Butler Road League City (Houston), TX 77573 Tel. +1(713) 621 7272 Fax. +1(713) 621 7279 Web: www.gedausa.com	GEDA RUS, LLC Tsentrlnaya str., build. 3/1, office H-208 141031 Nagornoye, Moscow region Russian Federation Tel. +7(495) 150-42-67 Fax. +7(495) 150-43-67 Web: www.geda-lift.ru
Turkey Subsidiary	Korea Subsidiary
GEDA MAJOR IS VE INSAAT MAKINALARI SAN. TIC. LTD. STI. Semsettin Günaltay Cad. No:224 A Blok K:2 D:5 Tüccarbasi/Erenköy TR-34734 Istanbul/Türkiye Tel.: +90 (216) 478 2108 Fax: +90 (216) 467 3564 Web: www.geda-major.com.tr	GEDA KOREA 1708, (MetroDioVill Bldg., Singongdeok-dong) 199, Baekbeom- ro, Mapo-gu, Seoul 04195 Korea Tel.: +82 2 6383-7001 Fax: +82 2 6383-7009 Web: www.gedakorea.com

1.5 Information about the author and industrial property rights

All documents are protected within the terms of the copyright law. Dissemination and reproduction of documents (including parts thereof), as well as reuse or disclosure of their contents, are prohibited unless expressly permitted in writing.

The copyright and conditions of use of any software/user documentation from other manufacturers that may be included within the scope of delivery must be observed.

Violations are an offence and incur an obligation to pay compensation. All rights to exercise industrial property rights are reserved by GEDA.

1.6 Patents

Some components in our machines are protected by patent rights. To find out how to request information about these, refer to <http://www.geda.de/>.

1.7 Instructions for the operating company

This operating manual is an essential component of the machine. The operating company must ensure that operating personnel are **informed** about these guidelines.

The operating company must supplement the operating manual with **operating instructions** based on existing national regulations for accident prevention and for the **protection of the environment**, including information regarding supervisory and reporting duties that take account of company-related specifics, e.g. with reference to work organisation, work procedures and the personnel employed.

In addition to the mandatory **regulations for accident prevention and industrial safety** that apply both in the country of use and at the place of use, accepted professional rules for safe and competent working must also be observed.

The operating company must ensure that operating personnel wear **personal protective equipment** appropriate to the local conditions.

First aid equipment (first aid kit, etc.) must be kept within reach!

The operating company/user of the machine **must not make any changes, additions or modifications** to the machine that could impair safety without permission from the manufacturer! This also applies to installing and adjusting safety devices as well as welding on load-bearing components.

Any **replacement and wearing parts** that are used must correspond to the technical requirements stipulated by GEDA . This is ensured with **original replacement parts**.

Only employ **qualified and/or trained personnel** for the tasks described in this manual.

The operating company clearly defines the responsibilities of the personnel for operation/installation/maintenance.

The operating company is obliged to instruct all people authorised to use the machine in the correct way to handle the machine based on their respective range of activities and responsibilities using practical exercises, before they use it for the first time.

This **training** must be documented and **repeated at regular intervals**.

The legally permissible minimum age must be observed!

1.8 Intended use

The MULTILIFT P22 is a rack and pinion hoist for temporary use on construction sites

- that may only be operated by instructed and authorised site personnel
- that is designed for the transport of material and persons who can exit the car at installed and secured exit points (landing level safety gates)
- which may only be operated at a wind speed of up to 72 km/h (20 m/sec.; wind force 7-8 on the Beaufort scale)
 - at higher wind speeds, the car must be parked on the ground and shut down

The instructions in chapter 3 Technical data must be observed and adhered to.

Any other use or any use going beyond this is not considered proper use.

The operating company/user of the machine is solely liable for any damage resulting from this. This applies equally to any unauthorised changes to the machine.

Intended use includes

- Compliance with the operation and maintenance instructions (operating manual) provided by the manufacturer
- Consideration of foreseeable misconduct of other persons
- Compliance with the corresponding national regulations

1.8.1 Assembly, service/maintenance specialist

A person who, due to qualified professional education, training and experience, is able to recognise risks and potential hazards during assembly/maintenance/repair work on the machine and subcomponents and can rectify these by introducing appropriate measures.

1.8.2 Operating personnel

The machine may only be operated by persons who, based on their training, knowledge and practical experience, can ensure proper handling.

These persons must

- have been appointed by the operating company
- have been appropriately instructed and informed about the risks
- be familiar with the operating manual
- observe national regulations.

1.8.3 Improper use

The MULTILIFT P22

- is not designed for permanent installation
- must not be set up to be free-standing (without anchoring)
- must not be operated by persons without instruction on the machine or by children The persons must be familiar with the operating manual.

Consequences of improper use of the machine

- Danger to life and limb of the user or a third party.
- Damage to the machine and other objects.

2 General safety information

The machine has been designed and built according to the state of the art and recognised safety rules.

Nevertheless, hazards for personnel or third parties and/or damage to machinery and other tangible assets can occur during use, e.g. if the machine:

- is operated by untrained or uninstructed personnel,
- is not used for the intended purpose,
- is assembled, operated and serviced inappropriately.

Attached notices and warning signs must be observed!

Consequences of failure to comply with safety instructions

Failure to comply with safety instructions can result in hazards for personnel as well as for the environment and the machine. Failure to comply can lead to any claims for damages becoming invalid.

2.1 Residual risks

Residual risks remain from handling the machinery even when all safety conditions are complied with.

Anyone who works on and with the machine must be aware of these hazards and follow instructions that prevent these residual risks leading to accidents or damage.

- Do not remove any safety labels; replace any safety instructions that have become illegible.
- Danger when entering and leaving the car.
- Hazard from damage to the mast sections, anchors or base unit.
- Hazard when working on the electrical system.
- Hazards from a malfunction in the control system.
- Hazards from uncoordinated working practices.
- Hazard from operating a machine that has not been maintained correctly.
- Hazard from high wind speeds > 72 km/h.

2.2 Safety instructions for operating personnel

The operating manual must be kept within reach at all times **at the location where the machine is used.**

The machine may only be used in a technically flawless condition, **in accordance with the intended use, in a safety conscious manner, with awareness for the hazards** and in compliance with this operating manual! In particular, faults that could impair safety must be eliminated immediately!

In addition, the machine may only be operated when all **safety devices are installed and functioning!**

Check the machine for externally identifiable damage and defects **at least once each working day!** Immediately report any changes (including changes to the operating behaviour) to the office/person in charge. If necessary, shut down and secure the machine immediately! The **responsibilities** for different jobs within the context of operation and maintenance of the machine must be clearly defined and adhered to. This is the only way to avoid mistakes, especially in hazardous situations.

The relevant **rules for the prevention of accidents**, as well as other, generally recognised health and safety rules must be adhered to.

The hoist operator is obligated to wear **personal protective equipment** appropriate to the local conditions.

Switch-on and shut-down procedures, including emergency shut-down, must be observed in accordance with the operating manual for all work that affects operation and for conversions and adjustments to the machine and its safety devices.

2.3 Safety instructions for transport

Immediately report **transport damage** and/or **missing parts** to the supplier.

During transport tasks, wear a **safety helmet, safety shoes and protective gloves!**

Never walk below suspended loads!

Only use **appropriate, standardised and tested lifting devices** (forklifts, cranes) and load attachment gear (lifting beam, round slings, lifting straps, rope slings, chains) for transport at the assembly site.

When selecting lifting and slinging equipment, always take into account the **maximum suspended loads!**

Dimensions and weights can be found in chapter 3 Technical data.

Only load and transport **the carefully dismantled, packed and lashed machine.**

Always ensure that the machine is transported **without being knocked or jolted**. Ensure that the machine is stable during transport. Support the platform before strapping it down for transport.

Observe the **symbols on the packaging.**

Only attach gear to the **designated attachment points.**

Always **secure transported loads against falling or tipping over!**

The machine must only be transported/installed on foundations with sufficient load capacity.

Ensure that stable balance is maintained when transporting with forklift trucks.

2.4 Safety instructions for operation

Only operate the machine in accordance with the operating manual, **when it is in full working order, and in a safety and hazard-conscious manner.**

If **work is interrupted, switch the machine off at the main switch** and secure it with a padlock against being switched on again.

Fundamentally, the machine must be **secured against unauthorised use** (disconnect from power)!

In situations that present a **risk to the operating personnel** or the machine, shut down the machine by pressing the **EMERGENCY STOP** button.

No persons are permitted to remain within the base enclosure. It is also not permitted to store any objects or materials there.

The machine must not be used as steps or a climbing aid. Only use tested and stable steps/climbing aids. Keep steps/climbing aids free of dirt and soiling.

Protection to prevent persons from falling must be provided at loading heights above 2.0 m. (Install landing level safety gates.)

Move load platform down and shut down machine at wind speeds of >72 km/h. (Wind force 7-8, wind breaks branches off trees, makes walking very difficult)

Any accompanying persons must comply with the **instructions given by the operator** and they must not step over material that is also being transported.

2.5 Safety instructions for maintenance and troubleshooting

Operating personnel must be **informed** about how to carry out special work and repair work before starting.

Deadlines that are stipulated or stated in the maintenance manual for recurring **tests/inspections** must be adhered to.

The **maintenance area** must be **cordoned off** extensively as required! Before carrying out any maintenance work on the machine, always

- unload it,
- switch it off at the main switch.

All **maintenance and repair work** is only permitted with the **main switch turned off** or **with the mains plug disconnected**. Manual intervention while the machine is running can lead to serious injuries and is therefore prohibited. If it is necessary to **switch the machine on during** such work, this must only be done while **complying with special safety measures**.



For further instructions on maintenance, maintenance intervals and servicing, refer to the maintenance manual.

If the machine has been completely shut down for these tasks, it must be secured against being switched on unintentionally:

- Actuate the **EMERGENCY STOP** button
- **Lock** the **main switch** using a shackle lock and
- attach a **warning notice** to the switch box (main switch).

Any faults that could impair safety must be rectified immediately.

Workshop **equipment that is suitable for the specific work** is absolutely necessary for carrying out **maintenance and inspection work**. When carrying out maintenance tasks at greater heights, a fall protection system must be worn! Keep all handles, railings and the platform free from dirt and contamination.

When working underneath the car, it must be secured against lowering with the setting mechanism.

Before starting service/repair tasks, **clean** any oil, operating fluids, contamination and maintenance products from the machine, paying special attention to connections and threaded connections. Do not use abrasive cleaning materials. **Screw connections that were released** during maintenance and inspection work must always be tightened again using the necessary **torques**!

Do not change, remove, bypass or bridge safety devices.

If it is necessary to dismantle safety devices during maintenance and repair work, the safety devices must be installed and checked immediately after completion of the maintenance and repair tasks!

Do not make any changes, additions or modifications to the machine. This also applies to the installation and adjustment of safety devices such as limit switches.

Immediately replace damaged or detached information and warning signs, as well as safety labels.

Ensure that operating and auxiliary materials, as well as replaced parts, are disposed of safely and in an environmentally friendly manner (see also chapter 6 Disposal).



The aforementioned safety measures also apply to troubleshooting.

2.6 Safety when working on the electric system

If there are **faults on the electrical system** of the machine, it must be **shut down immediately using the main switch** and secured with a padlock or the mains plug must be disconnected!

Work on the electrical equipment of the machine must only be carried out by **qualified electricians** working in accordance with electrical engineering regulations! Only professional electricians may access the electrical system of the machine and carry out work on them. **Always keep the switch boxes closed** whenever they are left unattended.

Never work on live parts! System parts on which inspection, maintenance or repair work is to be carried out must be **disconnected from the mains power**.

Operating equipment that has been disconnected must be secured against being switched back on unintentionally or automatically (lock away fuses, block isolating switches, etc.). The disconnected electrical components must first be tested to ensure they are voltage-free, then earthed, short-circuited and isolated from neighbouring live components.

If **tasks have to be carried out on live components** (only in exceptional circumstances), an additional person must be present to operate the **EMERGENCY STOP** button or main switch in the event of an emergency. Use only insulated tools!

During repairs, ensure that **design features** are not **modified** so that they have a negative influence on safety. (e.g. creeping distances, clearances and distances must not be reduced by insulation).

Fault-free **earthing** of the electrical system must be ensured by a **protective earth system**.

Changes to the control program can impair safe operation. All program changes require the manufacturer's approval.

3 Technical data

3.1 Operating and environmental conditions

The machine may only be operated when the following operating and environmental conditions are adhered to:

- Storage in dry rooms, in order to prevent corrosion.
- No jolts or vibrations.
- No abrasive, corrosive substances.
- The machine must be protected against pest damage (insects, rodents, etc.).
- Before transport/storage, the machine must be cleaned and checked for signs of damage.

Temperature range:	minimum	- 20 °C
	maximum	+40 °C
Humidity (relative):		80 % RH

Wind speed:

Operation/maintenance/repair	maximum	72 km/h
Assembly:	maximum	45 km/h

It may be necessary to cease or prohibit operation of the machine under extreme weather conditions, even if the operating and environmental conditions fall within the bounds of those stated. For example, if heavy frost and a storm occur together. In these cases, the operating company must provide appropriate regulations.

Do not use during storms (lightning)!

Atmosphere at the location of use during material transport

When transporting material, this must not lead to a concentration of abrasive/corrosive substances and of explosive fine dusts. If this cannot be safely excluded, the corrosion protection and/or the functional reliability of the electrical components must be checked at regular intervals and they should, if necessary, be replaced. Fine particulate matter must be removed.

Atmosphere at the location of use during passenger transport

The atmospheric composition on-site must be suitable for people to remain for longer periods in the area. In particular, a reduction in the oxygen concentration as a result of displacement or consumption must be prevented. The legal limit values for pollutant concentrations/aerosols and dust in the workplace must not be exceeded.

3.2 Emissions

Sound pressure level: < 78 L_{PA}

3.3 Tightening torques

Special mechanical screw connections with torque control

Mast - elements to one another		
Tightening torque		
300 Nm	220 lbf ft	
Width across flats (AF) 30 mm		
Couplings		
Tightening torque		
50 Nm	37 lbf ft	Couplings 1 ½"
100 Nm	74 lbf ft	Couplings 2 "
Flange connection trolley/floor assembly platform		
Tightening torque		
700 Nm	516 lbf ft	Cheese-head screw M24
Width across flats (AF) 36 mm		

General mechanical fittings without torque control

Tightening torques (All details refer to screws with strength class 8.8)					
M8	25 Nm	18 lbf ft	M18	300 Nm	221 lbf ft
M10	49 Nm	36 lbf ft	M20	425 Nm	313 lbf ft
M12	86 Nm	63 lbf ft	M22	575 Nm	524 lbf ft
M14	135 Nm	100 lbf ft	M24	710 Nm	524 lbf ft
M16	210 Nm	159 lbf ft	M30	1445 Nm	1066 lbf ft

Electrical screw connections

Tightening torques					
M4	1.2 Nm	0.88 lbf ft	M12	15.5 Nm	11 lbf ft
M5	2 Nm	1.47 lbf ft	M16	30 Nm	22 lbf ft
M6	3 Nm	2.21 lbf ft	M20	52 Nm	38 lbf ft
M8	6 Nm	4.42 lbf ft	M24	80 Nm	59 lbf ft
M10	10 Nm	7.37 lbf ft	M30	150 Nm	110 lbf ft

3.4 Electrical connected loads

A construction site distribution cabinet (in accordance with IEC 60439-4:2005) with a

- min. 3 x 63 A fuse protection of the supply point and a
- residual current device (RCD) are required

Base unit

Mains connection	380 - 480 V / 50 - 60 Hz / 3 Ph/PE
Fuse protection by customer	3 x 63 A slow-blow fuse
Protection rating	IP 54 (NEMA 3)
Mains plug	CEE 5 x 63 A, 6 h, red

Drive(s)	
Motor voltage:	380 V / 85 Hz
Power:	2 x 15 kW
Switch-on period (ED):	S1 (100%)
Power consumption:	2 x 30 A

Mains connection 32 A

In the case of the "Premium Package" option, a mains connection with smaller mains fuses can be configured.

Mains connection	380 - 480 V / 50 - 60 Hz / 3 Ph/PE
Fuse protection by customer	3 x 32 A slow-blow fuse
Protection rating	IP 54 (NEMA 3)

3.5 Speeds

Lifting speed

Operation (depending on load) 50 m/min. (at 1000 kg)

40 m/min. (at 2000 kg)

Exit door (B side)
with ramp 40 m/min.

Assembly max. 32 m/min.

Premium Package option

Operation (depending on load) 40 m/min. (at 0 kg)
with mains connection 32 A 30 m/min. (at 1000 kg)

Assembly 2 - 30 m/min. (adjustable)

Safety gear FV50

Triggering speed max. approx. 64 m/min.

Gravitational acceleration in the
car for **EMERGENCY OFF** < 1 g

3.6 Heights

Access height (threshold level): min. 0.45 m

Installed height (H): max. 200 m

Assembly site elevation:
(metres above sea level) max. 1000 m (3289')

3.7 Vibrations in the car

Symbols:

a = Effective value of acceleration not evaluated

a_w = Effective value of the frequency-weighted acceleration evaluated in accordance with ISO 2631-1:1997

$a_{wx} = a_w$ in m/s^2 for the x-direction with frequency weighting W_d

$a_{wy} = a_w$ in m/s^2 for the y-direction with frequency weighting W_d

$a_{wz} = a_w$ in m/s^2 for the z-direction with frequency weighting W_k

horizontal direction x

Directional door of the car

horizontal direction y

transverse to the x-direction

vertical direction z

Direction of travel

frequency-weighted vibration acceleration a_w			
Operating status	a_{wx}	a_{wy}	a_{wz}
Travel upwards / downwards	0,03 -0,1 m/s^2	0,03 -0,1 m/s^2	0,15-0,5 m/s^2

3.8 Mast

Only original GEDA mast sections may be used!

Vario MAST




Fig. 1: Vario Mast

Length 1495 mm

Weight 88 kg

Tightening torque (connecting screws) 300 Nm



Galvanised nuts on galvanised retaining strap without lubrication are a precondition for the tightening torque!

Trailing cable guides must be assembled in conjunction with the expected wind speeds. The more sensitive the hoist location is to wind forces, the shorter the distances should be between the trailing cable guides.



The distances to be observed for the cable guides are described in the assembly manual for the machine.

⚠ DANGER**Danger to life**

Limited overrun at the last mast bracket.
Dimension **W** is the top mast bracket to the top track rollers (approx. 0.5 m below the mast end).

- W** = Mast projection above the top mast bracket
[during operation and assembly]
- Z** = Maximum distance between the lower edge of the car/platform and the top mast bracket
- H** = Installed height
- G** = Vertical distance between mast brackets
- E** = Vertical distance between ground [foot section] and bottom mast bracket




Fig. 2: Anchoring diagram

	Max.	Min.
W = Operation:	10.5 m	-
Installation:	11.5 m	-
Z =	$W - 3 \text{ m}$	-
H =	200 m	-
G =	12 m	6 m
E =	6 m	3 m


Recommendation:

Even vertical spacing between the mast brackets should be ensured!

Inclination of mast
for vertical installation

max. **installation height (H)**
500

in X and Y direction



Example 1

Installed height = 50 m

50 m = 0.1 m

500

Example 2

Installed height = 100 m

100 m = 0.2 m

500



Check inclination during and following assembly using appropriate means.

During assembly, the maximum permitted distance between the car door and the landing level safety gate (see Assembly Manual) must be ensured.

3.9 Load capacity, dimensions and weights

Ladder in the car

Load capacity max. 150 kg / 330 lbs

Assembly crane

Load capacity max. 440 lbs / 200 kg

Assembly plank

Load capacity max. 150 kg



Installing additional equipment (e.g. additional floor covering made of steel/aluminium) increases the tare weight. This reduces the load capacity of the car accordingly.












Weights

Base unit with car and cable box approx. 3410 kg
(30 m flat cable)

Flat cable each 25 m + 50 kg

Load capacity

Operation max. 2000 kg/ 22 persons

1920 kg	+ 1	
1840 kg	+ 2	
1760 kg	+ 3	
1680 kg	+ 4	
1600 kg	+ 5	
1520 kg	+ 6	
1440 kg	+ 7	
1360 kg	+ 8	
1280 kg	+ 9	
1200 kg	+ 10	
1120 kg	+ 11	
1040 kg	+ 12	
960 kg	+ 13	
880 kg	+ 14	
800 kg	+ 15	
720 kg	+ 16	
640 kg	+ 17	
560 kg	+ 18	
480 kg	+ 19	
400 kg	+ 20	
320 kg	+ 21	
240 kg	+ 22	

Assembly 1000 kg

Car dimensions



Fig. 3: Dimensions of car

MULTILIFT P22	a	b	c	d	e	f	g	h
Dimensions in m	3.41	2.10	2.31	3.97	3.47	2.10	3.25	1.37

4 Operation

Operating personnel – see chapter “1.8.2 Operating personnel”

4.1 Safety during operation



Safety instructions in chapter 2 General safety information also have to be observed.

The Construction hoist is equipped with an overload detection device that switches off travel movement in both directions when the load capacity is exceeded and a status message is shown on the touch display.

- Observe the load capacity of the car.
 - The load must be evenly distributed across the car.
 - The car must always be loaded in such a way that the access points for loading and unloading and the control point are kept clear.
 - Position the load securely on the car. Any material that could slip or fall must be secured.
 - The maximum number of persons in the car is limited to 22 (incl. car operator). The proportion of material that can be transported is reduced according to the number of persons.
- Fall protection must be provided at loading heights above 2.0 m to prevent persons from falling. (Install landing level safety gates.)
- Fundamentally, secure the machine against unauthorised use! - At the end of work or during breaks, switch off the main switch and secure it with a padlock.
- If the loaded car stops during operation due to a malfunction, the operator has to recover the load. - Never leave a loaded car unattended!
- The unit is operated from outside of the hazard area or from the car control.
 - Comply with the instructions of the operator.
 - Do not step over material that is being transported.
- Operation must cease under the following conditions:
 - at temperatures below -20°C and above +40 °C.
 - in case of damage or other malfunctions.
 - A recurring inspection/intermediate inspection has been missed (refer to the maintenance manual).

DANGER



Danger to life

- Do not use in case of fire!

4.2 Commissioning




Fig. 4: Startup

- Turn the main switch (11) to the “I” [ON] position.



The double doors on the enclosure and the sliding door on the car have to be closed.

4.2.1 Fingerprint scanner (optional)

The car operator has to activate the control in the car using their fingerprint.



Fingerprint scanning is described in a separate operating manual for the fingerprint scanner.

A request to activate the control using the fingerprint scanner is shown on the car control touch display.



Fig. 5: Touch display fingerprint scanner

- Place your finger on the sensor surface (8A) for 2 s.
 - The green LED (8B) lights up as confirmation.
 - ✓ The car control is enabled.




Fig. 6: Touch display fingerprint scanner



The car control has to be activated every time the car doors are opened!

4.2.2 Safety check before starting work

Carry out a test run with an **empty** car and check to see whether

- the complete travel path is clear
- the door locks function correctly (refer to chapter 4.3.4 and 4.3.3)

The car must be immediately stopped if

- an **EMERGENCY STOP** button is pressed
- the **UP-END** stop bar has been reached or the trolley has reached the mast end
- the **DOWN-END** stop bar has been reached

The car must not start if

- the sliding door on the car is open
- the double doors of the base enclosure are open
- a landing level safety gate is open
- an **EMERGENCY STOP** button was pressed

4.3 Operation/function




Fig. 7: Multilift P22 overview 1

- | | | | |
|---|-------------------------------------|---|-------------------------------------|
| 1 | Car | 5 | Double door on base enclosure |
| 2 | Sliding door A-side of car | 6 | Foot section |
| 3 | Sliding door C-side of car (option) | 7 | Landing level safety gates (option) |
| 4 | Base enclosure | 8 | Mast section |




Fig. 8: Multilift P22 overview 2

- | | | | |
|----|----------------------|----|--------------|
| 11 | Assembly plank | 15 | Railings |
| 12 | Mast brackets | 16 | Cable holder |
| 13 | Assembly crane | 17 | Cable guide |
| 14 | Wind sensor (option) | 18 | Cable bin |

4.3.1 Functional description

- The car can only be started if the enclosure door, car doors and all landing level safety gates are closed.
- The car doors are locked. To enter the car, the enclosure door, the landing level safety gate and the car door must be opened individually. A car door can only be opened when the car is stationary in front of an enclosure door or landing level safety gate.
- Each stop position above has a landing level safety gate with manually operated sliding doors and double access doors which are locked. The landing level safety gates can only be opened when the car is stationary at this stop position.
- The downward travel path of the car is limited by a **DOWN** limit switch and the upward travel path is limited by an **UP** limit switch. If this limit switch is overrun due to a fault, the **EMERGENCY LIMIT** switch interrupts the **EMERGENCY STOP** safety circuit.
- Contact with the ground station is possible through the intercom in the car.
- The base unit can be extended with 1.5 m long mast sections up to a max. installation height of 200 m.

The control can be operated from the car, ground station or landing levels.

Exceptions:

During assembly, only the assembly control is active, all other control points are disabled, only the **EMERGENCY STOP** buttons remain functional.

For the drop test, only the drop test control is active, all other control points are disabled, only the **EMERGENCY STOP** buttons remain functional.

The MULTILIFT P22 can be assembled with or without clearance to the wall, depending on which design of sliding door (with or without ramp) is installed on the landing level side of the car. This car door also dictates which landing level safety gate (low [1.1 m] or high [approx. 2.0 m]) has to be used.

4.3.2 Base enclosure

The bottom stop position (ground station) is fitted with a 2.50 m high base enclosure. This base enclosure (1) protects against entry into the lower hazard area.

⚠ DANGER



Danger to life from lowering car

- Never remain inside the cordoned area/base enclosure during operation.
- Whilst working inside the base enclosure, switch off the main switch and secure it against being switched on. If necessary, activate the setting mechanism so the car can't travel downwards.




Fig. 9: Base enclosure

Opening/closing the double doors

The double doors of the base enclosure and the sliding door on the car must be opened individually to enter the car.



The enclosure double doors can only be opened when the car is at the ground station.

The double doors (1) are unlocked electromechanically if the car is stopped at the ground station by the **DOWN** limit switch.

Opening

- Push/pull hard on both handles (1A) at the same time to open the double doors.

Closing

- Push/pull hard on both handles (1A) at the same time to close the double doors.




Fig. 10: Double doors on the base enclosure

Emergency release

The emergency release for the base enclosure double doors can only be operated from the outside.

- For emergency release, insert the triangular key through the hole on the outside of the base enclosure.
- Turn it to the left (anticlockwise) until the double doors can be opened.



Fig. 11: Emergency release for the double doors

- Turn the key back after the lock has been released.



The triangular key is located in the document and tool box.

4.3.3 Car access points

Car doors protect people in the car from falling out of the car during transport.

4.3.3.1 Vertical sliding door

Car access at ground station/option for building car access

Opening

- Use the handle bar (2A) to push the sliding door (2) up to the stop

Closing

- Use the door frame (2B) to pull down the sliding door (2) until it is fully closed.




Fig. 12: Vertical sliding door

4.3.3.2 Vertical sliding door with ramp

Option for building car access

Opening from the outside

- Pull hard on the grab bar (3A) until the ramp (3D) is fully open.
- ✓ The sliding door (3) is automatically pushed up.

Closing from the outside

- Push the grab bar (3B) hard against the car until the ramp (3D) is fully closed.
- ✓ The sliding door (3) is automatically pulled down.



Fig. 13: Vertical sliding door from outside

Opening from the inside

- Use the handle bar (3B) to push the sliding door (3) up to the stop.
- ✓ The ramp (3D) lowers automatically with the sliding door (3).

Closing from the inside

- Use the door frame (3C) to pull down the sliding door (3) until it is fully closed.
- ✓ The ramp (3D) lifts automatically with the sliding door (3).




Fig. 14: Vertical sliding door from inside

4.3.3.3 Car door emergency release

The emergency release for the car sliding doors can only be operated from the outside.

- For emergency release, insert the triangular wrench through the hole on the outside of the sliding door into the lock.
- Turn the key to the right (clockwise).




Fig. 15: Car door emergency release

- opening the car sliding door.
- Once the interlock release has been actuated, turn the wrench back and remove it.



The triangular wrench is located in the document and tool box.

4.3.4 Securing loading and unloading points

To prevent persons falling, fall protection must be installed at **all** loading and unloading points where there is a risk of falling from a height of more than 2 m.

Landing level safety gates protect persons from falling at the stop position when the car is not at the stop position.

Landing level safety gates must ensure a safe transfer to from the car to the building.



Assembly is described in the respective assembly manual for the landing level safety gate.

4.3.4.1 "Standard/Standard Basic" landing level safety gate

Landing level safety gate "Standard" without tarpaulin / filler plate

Used for vertical sliding door **with** ramp



These landing level safety gates can only be opened once the loading ramp has been completely opened.



Fig. 16: Standard landing level safety gate no. 01217/01268



The "Standard Basic" landing level safety gate is delivered without railing tubes.

“Standard” landing level safety gate closed (tarpaulin)

(Option as per EN 16719)

The retrofit kit article no. 1130276 can be used to retrofit the “Standard” landing level safety gate with a tarpaulin.



These landing level safety gates can only be opened once the loading ramp has been completely opened.




Fig. 17: “Standard” landing level safety gate closed (tarpaulin)

“Standard” landing level safety gate closed (filler plate)

(Option as per EN 16719)



These landing level safety gates can only be opened once the loading ramp has been completely opened.



Fig. 18: “Standard” landing level safety gate closed (filler plate)

Opening

- Press the lever (1A) in the direction of the arrow and push open the sliding door (1).

Closing

- Close the sliding door (1) until the lever (1A) engages downwards.




Fig. 19: Opening/closing the
"Standard" landing level safety gate

4.3.4.2 "Comfort" landing level safety gate

Used for vertical sliding door **with** ramp



Landing level safety gate "Comfort" without tarpaulin / filler plate

It is only possible to open this landing level safety gate when the unfolded unloading ramp is in contact with the sill of the landing level safety gate.



Fig. 20: "Comfort" landing level safety gate no. 01212

"Comfort" landing level safety gate closed (tarpaulin)

(Option as per EN 16719)

The retrofit kit article no. 1130296 can be used to retrofit the "Comfort" landing level safety gate with a tarpaulin.




Fig. 21: "Comfort" landing level safety gate closed (tarpaulin)

“Comfort” landing level safety gate closed (filler plate)
(Option as per EN 16719)




Fig. 22: “Comfort” landing level safety gate closed (filler plate)

Opening

- Press the lever (2A) in the direction of the arrow and push open the sliding door (2).

Closing

- Close the sliding door (2) until the lever (2A) engages downwards.




Fig. 23: Opening/closing the “Comfort” landing level safety gate

4.3.4.3 Landing level double doors



It is only possible to open the landing level double doors when the interlock cam on the car releases the lock.




Fig. 24: Landing level double doors

Opening

- To open, pull hard on both handles (4A) or pull on them from the car and push both doors (4) towards the building/system.

Closing

- Use the handles (4A) on the doors (4) to close the doors towards the car until the lock (4B) engages.

Emergency release

The landing level double doors are also equipped with an emergency release for rescue and recovery.

- Insert the triangular key into the lock (5).
- Turn the key to the right (clockwise).
- Open the double doors (4) with some force.
- Remove the key.




Fig. 25: Emergency release on the landing level double doors

4.3.5 Ground control

The car can be called from the ground control. The car stops exactly at the ground station.

- 1 **EMERGENCY stop** button
- 11 **Main switch**
- 13 **CALL** button




Fig. 26: Ground control

- 14 **Code** display

Calling the car

- Press the **Call** button (13).
 - ✓ The button lights up to confirm the input until the car has arrived at the ground station.

Stopping the car

The car stops automatically at the ground station.

In an emergency, press the **EMERGENCY STOP** button.



The code display (14) shows the identical CODE numbers to the display on the car control.
 (CODE table see operating manual for the BL174 touch display)

4.3.6 Landing level modules

4.3.6.1 Landing level module with stop

The **UP** or **DOWN** direction can be selected from the electric modules at the landing levels. The exact stop at the next landing level is activated by pressing the **LANDING LEVEL** button.

- 3 **UP** button
(move to the top landing level)
- 4 **DOWN** button
(move down to the ground station)
- 5 **STOP AT LANDING LEVEL** button
(car stops at the next landing level)




Fig. 27: Landing level module for stop at landing level

Ascending

- Press and release the **DOWN** button (3).
 - ✓ The car moves directly to the top landing level and stops there.

Descending

- Press and release the **DOWN** button (4).
 - ✓ The car moves from any landing level down to the ground station.

Stop at landing level

- Briefly press the **STOP AT LANDING LEVEL** button (5).
 - ✓ The car stops at the next landing level in the direction of travel.

4.3.6.2 Landing level module with call control

The car can be called from the electric modules on the landing levels. The landing level stops at the landing level from which the car was called.

Calling the car

- Briefly press the **CALL** button (13) briefly.
 - The button lights up to confirm the input until the car has arrived at the stop position.
- ✓ As soon as it is ready, the car moves to the requested landing level.



Fig. 28: Landing level module for call control



Call button flashes **blue** – call control not active.
(e.g. car is near to the load limit or wind too strong)

Call button flashes **red** – malfunction (call control)



Programming the electric module for these landing level call controls is described in the Assembly Manual (ML050).

4.3.7 Car controls

4.3.7.1 G-SAC car control with rotary/ push button [Single Automatic Control]

The landing level can be directly pre-selected on the car control.




Fig. 29: Car control with rotary switch

- 1 **EMERGENCY stop** button
- 2 **LC 100** rotary switch
- 5 **STOP AT LANDING LEVEL** button
 - car stops at the next landing level or
 - recall function to the ground station
- 7 **TALK** button
- 10 **Display** for
 - destination
 - current position
 - direction of travel
 - payload
 - status code

Moving to a landing level

- Turn the rotary switch (2) until the desired landing level has been set.
 - While turning, the rotary switch (2) is backlit in blue.
 - ✓ The selected landing level is shown in the display (10).

After setting the required landing level

- Press the rotary switch (2).
 - To confirm, the background light flashes twice.
 - ✓ The car travels directly to the selected landing level.

Stop at landing level (stop at the next landing level)

- Briefly press the **STOP AT LANDING LEVEL** button (5).
 - The button (5) lights up as confirmation.
 - ✓ The car stops at the next landing level in the direction of travel.

Stopping the car

- In an emergency, press the **EMERGENCY STOP** button (1).

Recall function to the ground station

The second function of the **STOP AT LANDING LEVEL** button (5) is the recall function to the ground station.

This is described in the chapter “5.3.2.1 Recovery using the recall function”.

4.3.7.2 Car control G-SAC keypad [Single Automatic Control]

The landing level can be directly pre-selected on the car control.




Fig. 30: Car control with keypad

- 1 **EMERGENCY stop** button
- 2 **Keypad**
0 - 9 = Landing level selection
▶ = START button
X = STOP button
- 5 **STOP AT LANDING LEVEL** button
- car stops at the next landing level or
- recall function to the ground station
- 7 **TALK** button
- 10 **Display** for
- destination
- current position
- direction of travel
- payload
- status code

Moving to a landing level

- Enter the desired landing level on the keypad (2)
 - The selected landing level is shown in the display (10).

For example:

0 → Ground floor

1 → Landing level 1

10 → Landing level 10

- Press the **START** button (►) to confirm the input.
 - The display (10) shows the respective position and direction of travel.
 - ✓ The car moves directly to the selected landing level and stops there.

Stop at landing level (stop at the next landing level)

- Briefly press the **STOP AT LANDING LEVEL** button (5).
 - The button (5) lights up as confirmation.
 - ✓ The car stops at the next landing level in the direction of travel.

Stopping the car

- In an emergency, press the **EMERGENCY STOP** button (1).

Recall function to the ground station

The second function of the **STOP AT LANDING LEVEL** button (5) is the recall function to the ground station.

This is described in the chapter “5.3.2.1 Recovery using the recall function”.

4.3.8 Controls for special operation



These controls must be kept locked by the operating company!

The cover plate (8) has to be removed for inserting the control for special operation from the car.

- Use the triangular key to open the triangular bolt(s) (8A) and remove the cover plate (8).




Fig. 31: Example for removing the cover plate

The drop test control and assembly control are connected at the plug connection on the outside of the car, below the car control switch box.

- Disconnect the dummy plug (7) and connect the appropriate control.

- 9 Socket 230 V/50 Hz for connecting tools
- 10 Maintenance switch for enabling the switch box in the car
- 15 **Alarm** button




Fig. 32: Inserting control for special operation

4.3.8.1 Drop test control

The drop test control is used for checking the safety gear by means of a drop test.



The drop test control may only be operated by a technically competent person!

- 1 **EMERGENCY stop** button
- 2 **BRAKE RELEASE** buttons
- 3 **UP** button
- 4 **DOWN** button




Fig. 33 Drop test control



Operation of the drop test control is described in the Maintenance Manual.

4.3.8.2 Assembly control

The assembly control is used for assembly of the hoist.

- 1 **EMERGENCY stop** button
- 3 **UP** button
- 4 **DOWN** button
- 5 **RELEASE** button
(Press and hold before the move command until ascent or descent are complete.)
- 6 **SPEED** selector switch
(normal/slow)




Fig. 34 Assembly control



Operation of the assembly control is described in the Assembly Manual.

4.3.9 Emergency shutdown

In situations that present a risk to operating personnel or the car, the car can be shut down by pressing an **EMERGENCY STOP** button.

An **EMERGENCY STOP**-button is located

- at the car control
- at the ground control
- in the base enclosure



Fig. 35: EMERGENCY STOP button



EMERGENCY STOP slam buttons are equipped with a latching mechanism and remain active until they are manually unlocked again (turn red button to the right and pull it out).

4.4 Interrupting work – end of work

Switch off and secure the hoist when interrupting work and at the end of work.

- Move the car down to the ground station until it stops automatically.



If there is a risk of frost, move the platform up a little so that the DOWN limit switch is clear.

- Unload the car.
- Switch off the main switch (position “0” [OFF]).



Fig. 36 Main switch

- Lift the cover from the switch and attach a padlock.
- Close the padlock.
 - ✓ This secures the hoist against activation.



Fig. 37 Securing the main switch

- Disconnect the mains plug.

4.5 Equipment

4.5.1 Emergency call system

The emergency intercom system consists of an intercom module at the ground control and one at the car control.

If persons are locked in the car, they can contact ground personnel using the intercom system.

The intercom system establishes contact with the ground station.

Each intercom module features a **TALK** button (7).

To establish a connection

- Press the **TALK** button (7).
 - ✓ You can speak to the other party while the **TALK** button (7) is pressed.
(Send message)
- After sending your message, release the **TALK** button (7).
 - ✓ The message from the other party can be received.



Always speak into the microphone (7A)!




Fig. 38: Ground station emergency call




Fig. 39: Car emergency call



The emergency call device can also be used without power supply!

4.5.1.1 Alarm signal

If help is needed from outside, the **ALARM** (15) button can be used to trigger an acoustic signal.

- Press the **ALARM** button (15).
 - ✓ While the **ALARM** button (15) is pressed, a signal tone will sound at the ground station.

15 **ALARM** button




Fig. 40: Alarm button in the car

4.5.2 Lighting

Car lighting

The car lighting is always on as long as the main switch is turned on.



Fig. 41: Car lighting

⚠ WARNING



Glare

- Do not look directly into the LED lighting for a prolonged period.

Car control lighting

The LED lights (9) illuminate while the main switch is turned on.




Fig. 42: Car control lighting

4.5.3 Roof hatch and ladder

It is possible to access the car roof using the ladder and the roof hatch to carry out maintenance / service work or to evacuate passengers.




Fig. 43: Overview of roof hatch and ladder

- | | |
|---------------------------|----------------------|
| 1 Ladder | 4 Roof hatch |
| 2 Ladder interlock device | 5 Roof hatch locking |
| 3 Document and tool box | |

⚠ WARNING



Risk of injury from falling off the ladder.

- Only one person is allowed on the ladder at a time.
- Always hold on with at least one hand.
- Always face the ladder to ascend and descend.
- Keep the ladder free of dirt.

Position the ladder at the roof hatch

- Hold the ladder firmly.




Fig. 44: Ladder in the car

- Release the screw on the star handle and pull the sliding mount out of the ladder.




Fig. 45: Pull the ladder out of the mount

- Take the ladder out of the fixed mounts.




Fig. 46: Take the ladder out of the mount

- Hook the screws of the ladder onto the roof frame below the roof hatch.




Fig. 47: Attach the ladder to the roof hatch

- Remove the triangular wrench from the document and tool box in the car and insert it above the triangular bolt for the roof hatch lock.
- Release the lock by turning the triangular wrench anti-clockwise.
- Pivot the lock towards the roof.




Fig. 48: Unlock the roof hatch



The roof hatch can be opened from the outside without a tool.

- Open the roof hatch and, if necessary, take suitable measures to prevent it from slamming shut, e.g. in strong winds.




Fig. 49: Open the roof hatch

⚠ DANGER



Risk of death when stepping on the car roof without safety gear

- Access only in an EMERGENCY or for maintenance/service work.
- Wear fall protection (PPE).

4.5.4 Document and tool box

The documents and tool box contains:

- 1 x triangular key
 - for unlocking the car sliding doors
 - for opening the cover plate (insert assembly control or maintenance switch of the car control)
 - for opening the switch boxes



Fig. 50: Document box

- for opening the roof hatch

The documents and tool box should contain:

- Operating Manual and Maintenance Manual for the machine
- Spare parts lists
- Circuit diagrams
- Operating instructions from the operating company
- Rescue plan of the operating company

4.5.5 Operating hours counter

An operating hours counter (1) is installed in the car switch box to record the operating hours (motor operating time).



Fig. 51: Operating hours counter



The switch box must be opened to read the counter. The switch box may only be opened by a qualified electrician!

4.6 Accessories

4.6.1 Assembly crane

When assembling the mast, the assembly crane (1) can be used to lift the mast sections onto the already mounted mast.




Fig. 52: Assembly crane

- 2 Control for assembly crane
- 2A EMERGENCY STOP (only switches off the
- 2B Rocker switch for UP and DOWN




Fig. 53: Control for assembly crane

4.6.2 Assembly plank

An assembly plank is a fold-out platform on the roof of the car, which assists in anchoring the mast sections exclusively from the car (i.e. can also be used in front of a façade, without frontal scaffolding).



The assembly plank may only be used during assembly, maintenance or emergency rescue.




Fig. 54: Assembly plank

4.6.3 Cold package

The MULTILIFT P22 can be used down to a temperature of -20 °C. In countries where work is also carried out at lower temperatures, installation of a cold package is recommended.

A thermostat in the switch box of the platform switches off upward travel at temperatures below -20 °C.



Fig. 55: Cold package

4.6.4 Wind sensor (option)

The wind sensor measures the wind speed while the hoist is in operation.

CODE 33 will be shown on the touch display for the car control at a wind speed greater than 72 km/h.

Operation of the hoist continues to remain unrestricted.

The image is an example




Fig. 56: Wind sensor

Automatic descent (option)

The car descends automatically to the ground station when the max. permissible wind speed is reached during operation ≥ 72 km/h.



The car executes the actual command. It then automatically returns down to the ground station.

CODE 33 is shown on the touch display for the car control.

4.6.5 Lifting beam

The lifting beam is used for lifting the base unit with a crane.




Fig. 57: Lifting beam

Loading Capacity = max. 3500 kg

2 Lifting beam

2A Crane lugs

5 Malfunctions – diagnosis – repair

⚠ WARNING



Risk of injury from incorrect troubleshooting and fault elimination

- Troubleshooting and fault elimination may only be carried out by persons specially trained and authorized for this purpose.
- Before troubleshooting, always move the car down and unload it if possible!
- Immediately discontinue operation if faults occur that endanger operational safety!

⚠ DANGER



Electric shock from live parts

- Before working on the electrical system, switch off and lock the main switch. For safety reasons, disconnect the mains plug.

5.1 Status display in the touch display (HMI)

The touch display shows the destination, position of the car and the direction of travel.

In addition, it is also used for quick and easy identification of the switching statuses for the limit switches and the status of the system.

- 1 Destination
- 2 Car position
- 3 Direction of travel indicator
The arrow indicating the direction of travel during UP and DOWN travel.
- 4 Load display
- 5 Wind force




Fig. 58: Touch display (HMI)

Code messages with a yellow background indicate service or maintenance information.

- 6 CODE no.
- 7 Status symbol
- 8 Explanation




Fig. 59: Touch display – maintenance



Only the possible status messages and CODE numbers which are relevant for your machine are displayed!

Code messages with a red background indicate information about a malfunction.

The machine/hoist is not ready for operation!

- 6 CODE no.
- 7 Status symbol
- 8 Explanation




Fig. 60: Touch display – malfunction



If a CODE no. is displayed, the colour of the background lighting changes.

Actions for CODE display:

- Identify the **CODE** displayed and change/rectify the status.
- Wait until the control is automatically enabled.



The operation and description of the touch display are described in a separate operating manual. This manual is part of the machine documentation.

5.1.1**Malfunctions without status message**

Car does not move		
	Mains plug disconnected Mains fuses	Connect the mains plug Check mains fuse and replace/switch on if necessary
Car only moves upwards		
	Is the DOWN limit switch functioning properly	Check/replace the DOWN limit switch
Car only moves downwards		
	Is the UP limit switch functioning properly	Check/replace the UP limit switch
Drive motors are not providing full performance		
	Voltage drop of more than 10%	Refer to chapter 5.2.1
Enclosure double doors do not open		
	Car is not positioned exactly at the ground station	Move the car down to the DOWN limit switch

5.2 Rectify fault

5.2.1 Motor is not delivering full power

- Voltage drop of more than 10% of the rated voltage.
- Select cable with larger cross-section.
- If the motor is overloaded, the built-in thermal switch will switch off and the frequency converter goes into error mode. After a certain cooling period, the built-in thermal switch will switch back on.

⚠ CAUTION

Motor overload from overloading the machine

The motor heats up and the motor/brake service life is reduced.

5.2.2 Main switch/circuit breaker has tripped

Main switch/RCD/circuit breaker

If the circuit breaker has tripped, the main switch at the ground station switch box is in the **TRIP** position.



Fig. 61 Circuit breaker tripped

Resetting the main switch

- Turn the main switch to the **RESET** position and then to the **[ON]** setting.
- ✓ The circuit breaker is activated again.



Fig. 62 Resetting the circuit breaker

5.2.3 Car has moved too high

The car travels too high, i.e. the **EMERGENCY** limit switch reaches the **UP-END** stop bar.

Possible causes:

- the **UP** limit switch is defective
- there is a malfunction in the electrical system

Safe working

Free movement using the drop test control may only be carried out by a competent person specifically appointed by the operating company who, due to their training, knowledge and practical experience, are able to evaluate the risks.

The car has to be moved back down to the operating range of the mast using the drop test control.

Action:

- Connect the drop test control (refer to chapter 4.3.8 Controls for special operation or to the Maintenance Manual).
- Press the **DOWN** button (4) and lower the platform by approx. 1 m.
 - ✓ The car will move out of the **UP-END** position.
- After the clearance run, disconnect the drop test control again and plug in the dummy plug.




Fig. 63: Drop test control for clearance run

5.2.4 Car has moved too low

The car travels too low, i.e. the **EMERGENCY** limit switch reaches the **EMERGENCY-END** stop bar.

Possible causes:

- the brake clearance is too large
- the **DOWN** limit switch is defective
- there is a malfunction in the electrical system
- the car is overloaded
- the car was lowered with the manual brake release (emergency descent)

Safe working

Free movement using the drop test control may only be carried out by a competent person specifically appointed by the operating company who, due to their training, knowledge and practical experience, are able to evaluate the risks.

The car has to be moved back to the operating range of the mast with the drop test control (clearance run).

Action:

- Connect the drop test control (refer to chapter 4.3.8 Controls for special operation or to the Maintenance Manual).
- Press the **UP** button (3).
 - ✓ The car will move out of the **DOWN-END** position.
- After the clearance run, disconnect the drop test control again and plug in the dummy plug.




Fig. 64: Drop test control for clearance run

⚠ CAUTION



Damage to the foot section and car

The **UP** button (3) must be pressed because this control bypasses the **EMERGENCY** limit switch. If the red drop test control buttons (2) are pressed inadvertently, the motor brake will release and the car can drop down hard onto the foot section.



If this effect occurs repeatedly despite the car not being overloaded, have the brake checked and adjusted by a qualified person.

5.2.5 Car does not stop at the selected landing level

If the car runs past the selected landing level or stops at the wrong level, a reference run to the ground station must be carried out.

Carry out reference run

- Press the **STOP AT LANDING LEVEL** button (5) and hold for approx. 30 seconds.
 - ✓ After approx. 30 seconds, the car slowly (32m/min.) moves downwards to the ground station and stops there.




Fig. 65 Platform control

After the reference run, the car can be operated again as normal.

5.2.6 Monitoring the locking of the assembly crane

The assembly crane must not pivot towards the path of travel (mast) whilst moving. Thus, this must be locked in a secure position.



If the locking bolt is pulled out, the safety circuit is interrupted and it is not possible to travel via the car!

The locking bolt must also be removed when no assembly crane is installed.




Fig. 66: Locking bolt for assembly crane

- Push the locking bolt towards the holder and lock.

5.2.7 Overload indication

The car is equipped with an overload warning device which prevents it from being moved if it is overloaded.

If the car is overloaded, **CODE 30** is displayed.


“CODE 30” display

- Reduce the load in the car until **CODE 30** is no longer shown.
 - ✓ Only then is travel possible.

5.2.8 Safety gear has triggered

The hoist is equipped with safety gear that brakes if the speed of the car becomes excessive. If the safety gear was triggered, further travel is not possible.

CODE 14 is shown on the touch display for the car control.

⚠ WARNING	
	<p>Risk of death from the safety gear being triggered</p> <ul style="list-style-type: none">➤ All persons must exit the car.➤ Determine why the safety gear has engaged, secure the car and repair damage before releasing the safety gear!➤ The safety gear may only be released by a competent person who is specifically appointed by the operating company and who, due to their training, knowledge and practical experience, are able to evaluate the risks and assess the safe condition of the safety gear.



Triggering the safety gear is described in the maintenance manual.

5.3 Rescue after malfunction

Rescue may become necessary in the event that, e.g.

- there is no mains voltage.
- the electrical system malfunctions.
- the drive fails.
- the safety gear has triggered.



If the hoist supervisor does not feel confident or qualified to organise and carry out the rescue, please notify the relevant authorities. (fire brigade, technical support, works security).

5.3.1 Conduct in the event of a rescue/malfunction

- Obtain an overview of the situation.
- Remain calm and do not act in haste.
- Be cautious and thorough when assessing the situation!
 - Is anybody hurt?
- Keep unauthorised persons away.
- Contact any persons trapped in the car.
- Attempt to find the cause of the malfunction/defect on the system, e.g.
 - Power failure
 - Triggering of the safety gear
 - **CODE** shown in the touch display (if present)
- If necessary, inform the trapped persons about the planned procedure.
- Notify your supervisor of the malfunction.
- Notify any rescue services.



The sequence of measures can/must be amended by the attendant/rescue personnel depending on the specific situation.

5.3.2 Initial rescue measures

5.3.2.1 Recovery using the recall function

The recall function can be activated from the ground control or from the car control.



The recall function can only be executed with a functioning machine control!

Recall from the car control

- Press the **STOP AT LANDING LEVEL** button (5) and hold for approx. 30 s.
 - ✓ The car slowly returns to the ground station and stops there.




Fig. 67: Recall function, car control

Recall from the ground control

- Press the **CALL** button (13) and hold for approx. 30 s.
 - ✓ The car slowly returns to the ground station and stops there.




Fig. 68: Recall function, ground control

5.3.2.2 Rescue in the event of a status display

CODE messages indicate malfunctions in the hoist system or switching statuses of the limit switches.

- Identify the **CODE** message (refer to the touch display or the touch display manual).
- If possible, eliminate the displayed malfunction/switching status (refer to the **CODE** table in the instructions for the touch display).

- 6 CODE no.
- 7 Status symbol
- 8 Explanation




Fig. 69: Touch display, car



The **CODE** no. is also displayed on the ground control.

5.3.2.3 Self-rescue using EMERGENCY lowering device

In an emergency, the next lower landing level can be reached by releasing the motor brakes. Persons trapped may be able to evacuate in this way.



Moving the car downwards by releasing the motor brake is not possible if, e.g. the safety gear has been triggered (CODE 14).

Executing an EMERGENCY descent

ATTENTION

Descending too quickly will trigger the safety gear

This disables the car which will then initially need to be raised.

➤ Only lower the car very slowly!



Fig. 70: Overview of emergency descent

1 Lever

2 Triangular wrench

3 Position of cover plate for emergency descent

- Remove the triangular wrench and lever from the document and tool box.
- Release the triangular bolt.
- Move the cover plate (3) to the side and attach.




Fig. 71: Emergency descent 1

- Insert the lever through the opening in the side panelling (4) and guide it to the brake release lever (5) for the motor brake.




Fig. 72: Emergency descent 2

6 Car cutout

7 Motors

- Release the motor brake by carefully pulling the lever (1).
- ✓ The car will glide downwards.




Fig. 73: Emergency release for the car

ATTENTION

Motor brakes become very hot

Interrupt the descent every 1-2 m for 2 m in order to prevent overheating of the brake.

The length of a mast section can be used for orientation.

- When at the next landing level, release the lever (1).
- Stop so that the sills of the car door and landing level safety gate are at the same level.

If no fault is displayed on the car control, the passengers can exit the car as normal.

Otherwise the doors have to be unlocked.

Emergency release of the car door, refer to chapter 4.3.3.3


Emergency release of the landing level double doors, refer to chapter 4.3.4.3

After completing the rescue

- Remove the lever (1) and put it back in the document and tool box.
- Replace the cover plate (3) and secure again with the triangular bolt.

5.3.2.4 Exiting the car

If the car is not stopped at a landing level and the motor brake cannot be released, any trapped passengers have to be evacuated via the car roof.


⚠ WARNING	
	<p>Risk of death from the safety gear being triggered</p> <ul style="list-style-type: none"> ➤ All persons must exit the car. ➤ Determine why the safety gear has engaged, secure the car and repair damage before releasing the safety gear! ➤ The safety gear may only be released by a competent person who is specifically appointed by the operating company and who, due to their training, knowledge and practical experience, are able to evaluate the risks and assess the safe condition of the safety gear.

- Establish contact with the ground station via the intercom module and discuss how to proceed further.

Exiting the car through the roof hatch

The ladder and roof hatch can be used to access the car roof. Refer to chapter 4.5.3 Roof hatch and ladder

Exiting the car roof

⚠ DANGER	
	<p>Risk of death when stepping on the car roof without safety gear</p> <ul style="list-style-type: none"> ➤ Access only in an EMERGENCY or for maintenance/service work. ➤ Wear fall protection (PPE).

Exiting the car roof as stipulated in the operating company's rescue plan.

5.3.2.5 Recovery in accordance with emergency plan

Evacuation is carried out in accordance with the emergency plan/operating company's rescue plan.



A rescue plan must be prepared by the operating company and kept in a clearly visible place on the hoist!

5.4 Repair

ATTENTION

**Maintenance work carried out by untrained personnel**

- Repair work may only be carried out by trained and competent persons because it requires special expert knowledge and skills. Neither is explained in this Operating Manual.

When ordering spare parts, please provide the following:

- Type
- Year of construction
- Factory no.
- Operating voltage
- Quantity required

The name plate is located on the trolley of the base unit.



Spare parts must conform to the manufacturer's technical specifications! Only use original spare parts from GEDA.

For service or repair work, please contact our customer service department:

For the sales and customer service address, see chapter 1.4
Manufacturer's name and address

6 Disposal

At the end of its useful life, the machine may need to be inspected for operational safety in accordance with national regulations, disassembled correctly and scrapped in an environmentally friendly way according to national provisions.



It is prohibited to use parts from a machine that is being scrapped in other machines or to assemble such parts to produce a new machine.

During disposal of the machine components, observe the following:

- Drain and dispose of oil/grease in an environmentally friendly way.
- Recycle metal parts.
- Recycle plastic parts.

Recommendation:

Contact the manufacturer or commission a specialist company to handle disposal requirements in accordance with the applicable regulations.

6.1 Information about the service life for EAC



Operation of the assembly control is described in the Assembly Manual.

The machine has to be examined at the end of its service life or correctly disassembled and disposed of in an environmentally friendly manner according to national regulations.

Operating the machine after the end of its service life is not permitted!



GEDA GmbH
Mertinger Strasse 60
86663 Asbach-Bäumenheim
Tel.: +49 (0)9 06 / 98 09-0
Fax: +49 (0)9 06 / 98 09-50
E-Mail: info@geda.de
Web: www.geda.de
BL201 GB 2021-05